### INSTRUCTION MANUAL





Thank you for choosing our Autonics product. Please read the following safety considerations before use.

### Safety Considerations

\*\*Please observe all safety considerations for safe and proper product operation to avoid

★ ∆ symbol represents caution due to special circumstances in which hazards may occur. ⚠ Warning Failure to follow these instructions may result in serious injury or death.

▲ Caution Failure to follow these instructions may result in personal injury or product damage.

- 1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
  Failure to follow this instruction may result in fire, personal injury, or economic loss.
  2. Do not connect, repair, or inspect the unit while connected to a power source.
  Failure to follow this instruction may result in fire.
  3. Install the unit after considering counter plan against power failure.
  Failure to follow this instruction may result in personal injury, or economic loss.
  4. Re-supply power after min. 20 sec from disconnected power.
  Failure to follow this instruction may result in product damage or malfunction.
  5. Check 'Connections' before wiring.
  Failure to follow this instruction may result in fire.
  6. For installing the unit, ground it exclusively and use over AWG 18 (0.75mm²) ground cable.
  Failure to follow this instruction may result in electric shock.
  7. Do not disassemble or modify the unit.
  Failure to follow this instruction may result in electric shock, or fire.
  8. Insulate the connector not to be exposed.

- 8. Insulate the connector not to be exposed.
- Install the connector not to be exposed.
   Failure to follow this instruction may result in electric shock.

  Install the driver in the grounded housing or ground it directly.
   Failure to follow this instruction may result in electric shock, personal injury, or fire.
- 10. Do not touch the unit during or after operation for a while
- Failure to follow this instruction may result in electric shock, or burn due to high temperature of
- the surrace.

  11. Do not remove the connector during or after operation for a while.
  Failure to follow this instruction may result in electric shock, or product damage.

  12. Emergency stop directly when error occurs.
  Failure to follow this instruction may result in fire, or personal injury.

## **△** Caution


- When connecting the power input, use AWG 18 (0.75mm²) cable or over.
   Install over-current prevention device (e.g. the current breaker, etc) to connect the driver
- with power.
  Failure to follow this instruction may result in fire.
  3. Check the control input signal before supplying power to the driver.
  Failure to follow this instruction may result in personal injury or product damage by unexpected
- signal.

  Install a safety device to maintain the vertical position after turn off the power of this driver.

  Install a safety device to maintain the vertical position after turn off the power of this driver. Failure to follow this instruction may result in personal injury or product damage by releasing holding torque of the motor.
- 5. Use the unit within the rated specifications.

- 5. Use the unit within the rated specifications.
  Failure to follow this instruction may result in fire or product damage.
  6. Use dry cloth to clean the unit, and do not use water or organic solvent.
  Failure to follow this instruction may result in electric shock or fire.
  7. Do not use the unit in the place where flammable/explosive/corrosive gas, humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
  Failure to follow this instruction may result in fire or explosion.
  8. The driver may overheat depending on the environment.
  Install the unit in the well ventilated place and forced cooling with a cooling fan.
  Failure to follow this instruction may result in product damage and degradation.
  9. Keep metal chip, dust, and wire residue from flowing into the unit.
  Failure to follow this instruction may result in fire or product damage.
  10. Use the designated motor only.
  Failure to follow this instruction may result in fire or product damage.

### Ordering Information




### O AiSA Series

Set	Driver	Motor
AiSA-60MA	AiSA-D-60MA	AiA-M-60MA
AiSA-60LA	AiSA-D-60LA	AiA-M-60LA
AiSA-86MA	AiSA-D-86MA	AiA-M-86MA
AiSA-86LA	AiSA-D-86LA	AiA-M-86LA

- \*The above specifications are subject to change and some models may be
- discontinued without notice.
- \*Be sure to follow cautions written in the instruction manual and the technical escriptions (catalog, homepage)

### Specifications



- Weight\*s Approx. 900g (approx. 780g)

  \*\*1: Based on the ambient temperature 25°C, ambient humidity 55%RH, and STOP current 30%.

  \*\*2: Max. power consumption during operation. When changing the load rapidly, instantaneous peak current may increase. The capacity of power supply should be over 1.5 to 2 times of max. power consumption.
- ※3: RUN current varies depending on the input RUN frequency and max. RUN current at the moment varies also ※4: Max. input pulse frequency is max. frequency to be input and is not the same as max. pull-out frequency o

### ■ Driver Setting

### SW1: Function selection DIP switch

n direction, pulse input method, STOP current, gain setting, and test mode.

Setting switch	No.	Name	Function	Switch position		
Setting Switch		INO. INAITIE		runction	ON	OFF (factory default)
	2	1	DIR	Rotation direction	CCW	CW
	4	2	1P/2P	Pulse input method	1-pulse input method	2-pulse input method
	N   N   N   N   N   N   N   N   N   N	3	CD	STOP current	20% of max. RUN current	30% of max. RUN current
	- □	4	GM	Gain setting	High gain	Low gain
	→ <sup>z</sup> <sub>0</sub>	5 <sup>**1</sup>	RVD	Test mode	Test mode	Normal mode

X1: Set to OFF when using the device. It is only for the operation test in manufacturing process

### Pulse input method

X1-pulse input method
-CW: Rotation operation signal input
-CCW: Rotation direction signal input
([H]: Forward rotation, [L]: Reverse rotation)

※2-pulse input method -CW: Forward rotation signal input -CCW: Reverse rotation signal input ccw [H]

cw← → ccw \*[H]: Photocoupler ON (voltage of both ends 4-8VDC), [L]: Photocoupler OFF (voltage of both ends 0-0.5VDC) STOP current

-In order to decrease motor heat and current consumption at motor stopping moment (in case there is no input during the time of the double width of last input pulse), set the stop current supplied to the motor phase.

SW2: Resolution setting switch

Set the resolution of driver. The number of pulses per 1 rotation by resolution is each 500, 1000, 1600, 2000, 3200, 3600, 5000, 6400, 10000, 1000, 1000, 1000, 1000, 1000, 1000, 1000, 1000, 1000, 1000, 10

7200, 10000.				
Modified settin	g values are not appl	ied in the running sta	tus, and the values w	ill be applied after motor stopped.
Setting switch	Setting	Pulse/Revolution	Resolution	

0 (factory default)	500	2.5	
1	1000	5	
2	1600	8	
3	2000	10	
4	3200	16	
5	3600	18	
6	5000	25	
7	6400	32	
8	7200	36	
9	10000	50	
	1 2 3 4 5 6 7	1 1000 2 1600 3 2000 4 3200 5 3600 6 5000 7 6400 8 7200	1         1000         5           2         1600         8           3         2000         10           4         3200         16           5         3600         18           6         5000         25           7         6400         32           8         7200         36

### O SW3: Motor gain setting switch

orro: motor gam setting switch		
W3 shifts motor gain between high and low, epending on 4th pin in SW1.  Motor gain lotor gain is selectable from 32 gains. he larger gain is, the more improved transient response ecomes and the less error occurs.  At the lowest system load status, raise the gain value	Speed Under Proper Over  GAIN Over  Status	
until motor vibrates and set to 1 to 2 level lower	0.4114	

4th pip in SW1=ON

ettina switch	Tui piii		011		-tur piir iii Ovvi Oiv			
	Setting	GAIN	Setting	GAIN	Setting	GAIN	Setting	GAIN
PBCOK T	0	×1	8	×9	0	×17	8	×25
	1	×2	9	×10	1	×18	9	×26
	2	×3	Α	×11	2	×19	Α	×27
∞(국누)의	3	×4	В	×12	3	×20	В	×28
GAIN	4	×5	С	×13	4	×21	С	×29
	5	×6	D	×14	5	×22	D	×30
	6	×7	E	×15	6	×23	E	×31
	7	×8	F	×16	7	×24	F	×32

### SW4: In-Position setting switch

etting Value

ig sta	tus, and the values w	vill be applied after motor stopped.
onse		
9	Position	·
	1	
		Command
		position
	In-Position	
	(Fast response)	Time
	In-Position	
	(Accurate response)	
		Delay time: 50ms

# CÔNG TYMERSONS HẦN CÔNG NGHỆ HỢP

# Driver Unit Descriptions - Function selection DIP switch (SW1) Resolution setting switch (SW2) Motor gain setting switch (SW3) - In-Position setting switch (SW4) - I/O connector (CN3)

■ Status	s Dis	play			
Indicator & Display part	LED color	Function	Descriptions		
	Green	Power indicator	Turns ON when the unit operates normally after supplying power		
PWR/ALM	Red	Alarm indicator	When alarm occurs, it flashes in various ways depending on the situation.  Refer to © Control Input/Output > Output > 2. Alarm'.		
INP	Orange	In-Position indicator	Turns ON when motor is placed at command position after positioning input.		
			Turns ON when Servo is operating, turns OFF when servo is not operating.		
Alarm/Status	Red	Alarm, status	When alarm occurs, it displays number of the corresponding alarm		

### Driver Connectors

ı	Connector fun					
ı	CN1: Motor+Encod	der con	nector			CN2: Power
ı	Pin arrangement	Pin No.	Function	Pin No.	Function	Pin arrangeme
ı	7 0 0 14	1	GND	8	+5VDC	
ı	6 🗆 🗆 13	2	Encoder A	9	Encoder A	1 1
ı		3	Encoder B	10	Encoder B	3 🗟
ı		4	Encoder Z	11	Encoder Z	4 9
ı		5	PE	12	N-C	6
ı	2 🗆 🗈 9	6	Motor A	13	Motor B	


	Pin arrangement		Pin No.	Input/	Fun	ction		
CN3: I/O connector								
	1 💷 8	7	Mot	or Ā	14	Motor B		
	2 0 0 9	6	Mot	or A	13	Motor B		
		5	PE	IA	12	N-C		
		4	Enc	oder Z	11	Encoder Z	П	
		3	Enc	oder B	10	Encoder B		
	6 🗇 🗖 13	2	Enc	oder A	9	Encoder A		


Pin arrangement	Pin No.	Input/ Output	Function	Pin No.	Input/ Output	Function
	1	Input	CW+	11	Output	In-Position+
0	2	Input	CW-	12	Output	In-Position-
	3	Input	CCW+	13	_	N-C
1   🗐   11	4	Input	CCW-	14	_	N-C
1	5	Input	Servo On/Off+	15	Output	Encoder A
:    6 8    :	6	Input	Servo On/Off-	16	Output	Encoder A
10[[텔]20	7	Output	Alarm Out+	17	Output	Encoder B
	8	Output	Alarm Out-	18	Output	Encoder B
0	9	Input	Alarm Reset+	19	Output	Encoder Z
	10	Input	Alarm Reset-	20	Output	Encoder Z

### Connector specifications

pe		Specifications	Manufacture				
		Connector Connector terminal Housing		Housing	Iviariulaciure		
11	Motor+Encoder	5557-14R	5556T	_	Molex		
12	Power	5ESDVM-06P-OR	_	_	Dinkle		
		10120-3000PE	_	10320-52F0-008	3M		
13		CJ-MP20-HP			Autonics		
	(sold separately)			Autonics			
hove connectors are suitable for AiSA-D Series							

# O Cable (sold separately)





Output

Contro Input/Output

Stop the motor for using the signal.
 Refer to example of input circuit connection
 Alarm Reset

This signal is for clearing the alarm

Input pulse (CW, CCW)

 $R_{L} = \frac{V_{CC} - 2.17V}{0.011A} - 220\Omega$ 

External input (Servo On/Off, Alarm Reset)

**■** Connection for Motor and Driver

CW- 0-2 220Ω 220Ω

Servo On/Off+ ο 5

Alarm Out+ • 7 10Ω Alarm Out- 0 8 Alarm Reset+ 

9 10kΩ Alarm Reset- ○ 10 In-Position+ • 11

In-Position- 12

N-C 0—13

N-C 0—14

Encoder A • 16

Encoder B - 18

Encoder Z • 19

Encoder Z̄ 0—20

Options for Power Connector (CN2)

2200

+24VDC

nt Pin No. Function

1. Position command pulse
Pulse input is selectable from 1-pulse input method and 2-pulse input method.

(Refer to '© SW1: Function selection DIP switch'.)

-When using extending cable, it is recommended to connect Common mode choke coil (2mH) to the CW, CCW terminal in series connection.

2. Servo On/Off

-This signal is for rotating axis of motor using external force or used for manual positioning.

-Servo On/Off signal maintains over 1ms as [H]

: Regarded as Servo Off signal and phase current is cut to release torque.

The Servo On indicator, the In-Position output and indicator turns OFF.

-Servo On/Off signal maintains over 1ms as [L]

: Regarded as Servo On signal and phase current is supplied to gain torque.

The Servo ON indicator, the In-Position output and indicator turns ON.

\*\*Stop the motor for using the signal.

In is signal is for clearing the alarm.
 Alarm reset signal maintains over 20ms as [H]
 Alarm is cleared, the alarm indicator and alarm output turns OFF, and the driver returns to normal status.
 Xif the causes of the alarm are not removed, driver may not be returned to the normal status even with alarm re
 Xerefer to example of input circuit connection.
 Example of input circuit connection

+24VDC

Motor

: Output

(8) +5VDC

GND GND

In puts pulse (Viv. CGW) it is recommended to use 5VDC at  $V_{\rm cc}$  and short the  $R_{\rm c}$ . In case  $V_{\rm cc}$  is over 5VDC, calculate  $R_{\rm c}$  value using following formula and use  $V_{\rm cc}$  below 30VDC.

$$\begin{split} & \times R_{\text{L}} = \frac{V_{\text{CC}}\text{-}2.17V}{0.011A} - 220\Omega \\ & -\text{In case } V_{\text{cc}} \text{ is } 12, 24VDC, \text{ refer to table on the right for } R_{\text{L}}. \\ & \frac{12VDC}{24VDC} \quad \begin{array}{c} 680\Omega \text{ (min. } 0.25W)}{1.8k\Omega \text{ (min. } 0.5W)} \end{split}$$

Input1. Position command pulse

1. In-Position

1. In-Position
-In-Position output is output condition of positioning completion signal.
-If the gap between target position and real position is under In-Position setting value after position command pulse has finished, In-Position output turns to [I-I] and the In-Position indicator turns ON.
-In reverse, when the gap is over In-Position setting value, In-Position output turns to [L] and the In-Position indicator turns OFF.
-For accurate drive, check the In-Position output again and execute the next drive.

\*Refer to example of output circuit connection.

2. Alarm/Warning


• Alarm


• Alarm


Alarm/Status display
-When alarm occurs, the alarm indicator (ALM, red) flashes as the times of corresponding alarm type.

	ALM flashing times	Alarm/ Status	Alarm type	Descriptions	Motor stop	Maintain torque
set.	1	1	Over current error	When over current flows at motor RUN element		×
	2	2	Over speed error	When motor speed is over 3,500rpm		
	3	3	Position tracking error	When the gap between position command value and current position value is over 90°		
	4	4	Over load error	When applying load over the rated load for over 1 sec		
	5	5	Over heat error	When heatsink temperature is over 90°C		
	6	Б	Motor connection error	When motor cable connection error occurs at driver		
	7	7	Encoder connection error	When encoder cable connection error occurs at driver		
	8	В	Overvoltage error	When input voltage is over 240VAC +10%		
	9	9	Undervoltage error <sup>*1</sup>	When input voltage is under 200VAC -10%		
	10	R	Motor misalignment	When motor is in misalignment		
- 1	11	Ь	Command pulse error	When input pulse is over 3,500rpm		
				When pulse is input before initial alignment		
	12	Ε	In-Position error	When position error (over 1) is kept over 3 sec, after motor stopped.		
	12	Ε		When position error (over 1) is kept over 3 sec,		

3. Example of output circuit connection It is recommended to use below 50VDC at  $V_{\rm CC}$ . Use the  $R_{\rm L}$  for  $I_{\rm C}$  (collector current of secondary detector) of photocoupler inside the driver to be within 25mA following the below formula.  $\times$ B, C: R<sub>L</sub>=  $\frac{V_{CC}-0.3V}{0.025A}$  - 10Ω







\*It is recommended to use Line driver output (corresponding to 26C32) at RECEIVER end of encoder output and terminating resisters (100-150Ω) in parallel at both ends of each phase (A, A, B, B, Z, Z, corresponding to 26C31).

# ■ Troubleshooting

| The University of the Company of

### Cautions during Use

■ Cautions during Use

1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.

2. Do not input CW, CCW signal at the same time in 2-pulse input method.

3. When the signal input voltage is exceeded the rated voltage, connect additional resistance at the outside.

4. To extend the motor+encoder cable, use the designated the cable.

5. Keep the distance between power cable and signal cable more than 10cm.

6. Install the unit vertically on the alarm/status display part upper side.

7. For heat radiation of the driver, install a fan.

8. Do not change any setting switches (function, resolution, motor gain, in-position switches) during the operation or after supplying power.

Failure to follow this instruction may result in malfunction.

9. Motor vibration and noise can occur in specific frequency period

©Change motor installation method or attach the damper.

①Change motor installation method or attach the damper

②Use and set the gain value.

©Use and set the gain value.

10. For using motor, it is recommended to maintenance and inspection regularly.

©Unwinding bolts and connection parts for the unit installation and load connection

©Strange sound from ball bearing of the unit

©Damage and stress of lead cable of the unit

@Connection error with motor

©Inconsistency between the axis of motor output and the center, concentric (eccentric, declination) of the load, etc.

11. This product does not prepare protection function for a motor.

11. This unit may be used in the following environments.

Olndoors (in the environment condition rated in 'Specifications')

Opollution degree 2 ②Altitude max. 2,000m ④Installation category II

## ■ Maior Products

# **Autonics** Corporation

DRW180069AE