Non Safety Picking Sensor

- Sensing distance of 3 m.
- Selectable display mode (all lighting, all flashing, elevator-like lighting, accordion-like lighting).
- Six picking indicators provide a very clear display.
- .Selectable display speed (SLOW/FAST).
- External picking indicators may be connected.
- •External indicators can be directly connected to the Picking Sensor and mounted in an easy-to-see location.

Compact, Resistant to Mutual Interference, and Ideal for Picking a Variety of Parts



Ordering Information

Sensors

Sensing method	Appearance	Connection method	Sensing dis- tance	Optical- axis pitch	No. of optical axes	Detecting height (mm)	Output type	External in- dicator	Model
		Pre-wired		25 mm	5	100	NPN		F3W-D052A
Through-		(5 m)					open collector	Possible	F3W-D052AP
		Connector							F3W-D052B
		(2 m)						Possible	F3W-D052BP
beam		Pre-wired	3 m				PNP		F3W-D052C
		(5 m)	NDUSTR	IAL A	UTO	ΜΑΤΙΟ	open	Possible	F3W-D052CP
		Connector	1 I 1 I				CONECTO		F3W-D052D
	•	(2 m)						Possible	F3W-D052DP

⚠ WARNING:

Do not apply F3W-D as safety mechanisms used in pressing machines or any other safety mechanisms for protecting the human body from danger

Accessories (Sold Separately)

Mounting Brackets

Appearance	Model	Quantity	Remarks
4	F39-L10	2	L-shaped Mounting Bracket
	F39-L11	2	Flat Mounting Bracket

Protective Bracket

Appearance	Model	Quantity
	F39-L12	One each for Emitter and Re- ceiver (mounting screws includ- ed)

OMRON

Y-shaped Joint Plugs and Sockets (Double-ended Connectors)

Appearance	Overall length	Model	Quantity
10	2 m	XS2R-D526- S001-2	1
as as	5 m	XS2R-D526- S001-5	1

Y-shaped Joint Plugs and Sockets without Cable

Appearance	Model	Quantity	Remarks
5	XS2R-D526- S003	1	Connecting ca- ble: Double-ended connector: XS2W Series Single-ended connector: XS2F-series 4- conductor mod- els



INDUSTRIAL AUTOMATION

OMRON

Ratings / Characteristics

PNP Output

Item		Through-beam			
nem		F3W-D052C(P) (see note 1)	F3W-D052D(P) (see note 1)		
Sensing distance		3 m, switchable between LONG mode (1 to 3 m) and SHORT mode: (0.05 to 1 m), factory-set to SHORT mode			
Optical-axis pitch		25 mm			
No. of optical axes		5			
Detecting height		100 mm			
Sensing object		Opaque, 35 mm dia. min.,			
Light source (wav	elength)	Infrared LED (860 nm)			
Power supply volt	age	12 to 24 VDC±10% (ripple range (p-p): 10%	max.)		
Power consumption	on	Emitter: 0.6 W max., Receiver: 0.7 W max.			
Control output		PNP open collector with 100 mA max. at 30 Residual voltage: 2,5 V max. at 100 mA Dark ON or Light ON (selectable)	VDC		
Picking instruction indicator input		Open collector with relay or transistor input Indicator ON: Input voltage of 0 to 2 V Indicator OFF: Open (with leakage current of 0.1 mA max.)			
Protection circuit		Reverse-connection protection, output short protection, and mutual interference interrupt- ing function (set with frequency selector switch)			
Response time		Operate/Release: 10 ms max.			
	Receiver	Operation indicator (orange), stability indicator (green), and 6 picking indicators (orange)			
Indicator	Emitter	Power indicator (green), different frequency i ange)	indicator (green), and 6 picking indicators (or-		
Ambient temperat	ure	Operating: -10° to 55°C Storage: -25° to 70°C (with no icing or condensation)			
Ambient humidity		35 to 85% (with no condensation)			
Insulation resistan	ice	20 MΩ min. (at 500 VDC)			
Dielectric strength		1,000 VAC 50/60 Hz for 1 min			
Vibration resistant	ce	Destruction: 10 to 50 Hz, 1.5-mm double-amplitude for 2 hours each in X, Y and Z directions			
Shock resistance	IN	Destruction: 500 m/s2, 3 times each in X, Y and Z directions			
Degree of protecti	on	IEC60529: IP62 (with the operation cover clo	osed)		
Connection method		Pre-wired Standard cable length: 5 m	Connector (M12 5-pin connector) Standard cable length: 2 m		
Weight (including package)		Approx. 360 g	Approx. 230 g		
	Case, display window	ABS resin			
Materials	Lens	Acrylic resin			
	Operation cover	Nylon (PA6)			
Accessories		Instruction manual			

Note: 1 . The F3W-D052 P Emitters are provided with the external picking indicator output line shown in the following table.

Item	F3W-D052CP, F3W-D052DP		
Connection method	Pre-wired with connector (standard cable length: 300 mm) Connector model: SMP-02V-NC (manufactured by Nihon Crimp Terminal, Ltd.)		
Electrical specifications	Output current: 50 mA max. Output voltage: Fixed at sensor power supply voltage		

NPN Output

Itom		Through-beam				
Item			F3W-D052A(P) (see note 1)	F3W-D052B(P) (see note 1)		
Sensing distance		3 m, switchable between LONG mode (1 to 3 m) and SHORT mode: (0.05 to 1 m), factory-set to SHORT mode				
Optical-axis pitch			25 mm			
No. of optical axes	6		5			
Detecting height			100 mm			
Sensing object			Opaque, 35 mm dia. min.,			
Light source (wav	elength)		Infrared LED (860 nm)			
Power supply volta	age		12 to 24 VDC±10% (ripple range (p-p): 10%	max.)		
Power consumption	วท		Emitter: 0.6 W max., Receiver: 0.7 W max.			
Control output			NPN open collector with 100 mA max. at 30 Residual voltage: 1 V max. at 100 mA Dark ON or Light ON (selectable)	VDC		
Picking instruction indicator input			Open collector with relay or transistor input Indicator ON: Input voltage of 0 to 2 V Indicator OFF: Open (with leakage current of 0.1 mA max.)			
Protection circuit	Protection circuit		Reverse-connection protection, output short protection, and mutual interference interrupt- ing function (set with frequency selector switch)			
Response time			Operate/Release: 10 ms max.			
	Receiver		Operation indicator (orange), stability indicator (green), and 6 picking indicators (orange)			
Indicator	Emitter		Power indicator (green), different frequency i ange)	indicator (green), and 6 picking indicators (or-		
Ambient temperat	ure		Operating: -10° to 55°C Storage: -25° to 70°C (with no icing or condensation)			
Ambient humidity			35 to 85% (with no condensation)			
Insulation resistan	ice		20 MΩ min. (at 500 VDC)			
Dielectric strength	l		1,000 VAC 50/60 Hz for 1 min			
Vibration resistance	ce		Destruction: 10 to 50 Hz, 1.5-mm double-amplitude for 2 hours each in X, Y and Z direc- tions			
Shock resistance			Destruction: 500 m/s2, 3 times each in X, Y and Z directions			
Degree of protecti	on		IEC60529: IP62 (with the operation cover clo	osed)		
Connection method			Pre-wired Standard cable length: 5 m (see note 2)	Connector (M12 5-pin connector) Standard cable length: 2 m (see note 2)		
Weight (including	package)		Approx. 360 g	Approx. 230 g		
	Case, display wind	low	ABS resin			
Materials	Lens		Acrylic resin			
	Operation cover		Nylon (PA6)			
Accessories			Instruction manual			

Note: 1 . The F3W-D052 DP Emitters are provided with the external picking indicator output line shown in the following table.

Item	F3W-D052AP, F3W-D052BP		
Connection method	Pre-wired with connector (standard cable length: 300 mm) Connector model: SMP-02V-NC (manufactured by Nihon Crimp Terminal, Ltd.)		
Electrical specifications	Output current: 50 mA max. Output voltage: Fixed at sensor power supply voltage		

2 . The following cable lengths are also available. F3W-D052A(P): 2 m, 7 m F3W-D052B(P): 1 m, 3.5 m $\,$

OMRON

Engineering Data



(Direction of swing) (Direction of rotation)

OMRON

CÔNG TY CỔ PHẦN CÔNG NGHỆ HỢP LONG

Nomenclature



NPN Open Collector Output Models

Emitter

F3W-D052A(P)-L F3W-D052B(P)-L Receiver F3W-D052A(P)-D F3W-D052B(P)-D

PNP Open Collector Output Models

Emitter F3W-D052C(P)-L F3W-D052D(P)-L Receiver F3W-D052C(P)-D F3W-D052D(P)-D



INDUSTRIAL AUTOMATION

OMRON

Operation

Output Circuits NPN



Output Circuits PNP Output form PNP open collector output Model F3W-D052C, F3W-D052CP, F3W-D052D, F3W-D052DP Dark-ON mode Light-ON mode State of output transistor ON: One optical axis or more is interrupted ON: No optical axis is interrupted OFF: No optical axis is interrupted OFF: One optical axis or more is interrupted No optical axis is interrupted No optical axis is interrupted Light incident Light incident One optical axis or more is interrupted One optical axis or more is interrupted ON ON Operation indicator (orange) Operation indicator (orange) OFF Timing chart OFF ON ON Control output Control output OFF OFF Operate Operate Release Load (relay, etc.) Load (relay, etc.) Release Mode Selector D.ON (Dark-ON) L.ON (Light-ON) F3W-D052C -L/D -L Sync.line F3W-D052CO-D/DO-D (5) Sy Orenge/purple (5) Orenge/purple Stabilit Picking Power B Freque Output Picking incident tor indica ~⊖ ~∩ ŶΦ (1) Brown (1) Brown A 12 to 24V External Picking Indicator DC Receiver Main circuit Emotter Main circuit 5V output Output circuit (2) Pink (2) Bro Load Pin Picking nstruction input Control (4) Output Black Blu Load (3) (3) BI *The inside of the speck chain line is only F3W-D052CP-L/DP-L Numerical value inside parenthesis,(),indicates a pin number of the connector of the sensor.

INDUSTRIAL AUTOMATION

OMRON

Dimensions



Note: All units are in millimeters unless otherwise indicated

Accessories (Sold Separately)

Mounting Brackets



Protective Bracket

F39-L12 (Receiver)



Mounting screws provided



Note: The Emitter and Receiver are axially symmetrical.





Y-shaped Joint Plugs and Sockets without cable

XS2R-D526-S003







Precautions

△ Warning:

Do not apply the F3W-D as safety mechanisms used in pressing machines or any other safety mechanisms for protecting the human body from danger.

- Do not apply the F3W-D as safety mechanisms used in pressing machines, shears, rolling machines, spinning machines, cotton mill machines, or robots for the protection of an operator's hands and body
- 2. The F3W-D is designed for detection of the human body or moving objects in the detection area but not for protection against danger.
- The F3W-D or any product incorporating the F3W-D may be exported to any country. Should the F3W-D cause any problem conflicting with the local law or related to product liability locally, however, OMRON shall, without exception, assume no responsibility for it.

△ Caution

Before using more than one F3W-D Unit in parallel or serial, take necessary countermeasures against mutual interference so that the unit will not malfunction. Refer to *Mutual Interference Attenuating Function*.

General Precautions

Supply Voltage

Make sure that the supply voltage is within the rated range. If the supply voltage is not within the rated range or 100 VAC is imposed on a DC Sensor model, the Sensor may be damaged or malfunction.

Load Short-circuiting

Do not short-circuit the load, otherwise the Sensor may be damaged or malfunction.

Incorrect Wiring

Do not make mistakes in the polarity of power supply or wiring, otherwise the Sensor may be damaged or malfunction.

Connection without Load

Make sure that the load is connected to the Sensor in operation, otherwise the Sensor may be damaged or malfunction.

Operating Environment

Do not use the Sensor in an environment containing flammable or explosive gases.

Do not use the Sensor underwater.

Do not disassemble, repair, or modify the Sensor.

Always turn OFF the system power before installing or replacing the Sensor.

System Design

Cables

For both pre-wired and connector models, the maximum tensile force of cables must be 50 N.

Wiring

If the Sensor cables are housed in the same conduit or duct as for high-voltage and power lines, the Sensor may be subject to induced current, resulting in malfunction or damage. For this reason, the Sensor cables must be separated from the high-voltage and power lines or housed in a separate conduit.

Power ON Timing

It takes 100 ms for the Sensor to operate properly after it is turned ON. Therefore, other devices should be turned ON at least 100 ms after the Sensor is turned ON. If the Sensor and the load are connected to different power supplies, the Sensor power must be turned ON first.

Power Supply

When using a commercially available switching regulator, always ground it to the frame ground (FG) or ground (G) terminal. Otherwise, switching noise may result in malfunctions.

Mutual Interference Attenuating Function

1. Two Sets of Sensors:

Set these Sensors to different frequencies with the frequency selector. Refer to *DIP Switch 1 Mode Switching* later in this datasheet.

If the mutual interference attenuating function is not used, and there are two Sensors with the same frequency setting, a beam from the Emitter of one Sensor may hit the Receiver of the other Sensor, resulting in malfunction.

This function cannot prevent mutual interference between the F3W-D Sensor and a Photoelectric Sensor of another model.

2. Three or More Sets of Sensors:

When 3 or more sets of Sensors are used in parallel, mutual interference may result in malfunction. Take the following measures to prevent mutual interference, and check for mutual interference.

- While in LONG mode, the Sensors are more easily affected by interference. Therefore, if the distance between the Emitter and Receiver of a Sensor is 1 m or less, use the SHORT mode.
- The distance between two adjacent sets of Sensors must be at least l₁ or l₂, which does not cause mutual interference between two Sensors with the same frequency setting. l₁ or l₂ is at least 1.5 times the distance shown in *Parallel Operating Range* of the *Engineering Data*.

Receiver

Ø

Re



· Install a barrier so that there will not be mutual interference between Sensors with the same frequency setting. (See Figure 1.)

A light reflection from the wall or floor may go around a barrier and reach the Receivers. Install a barrier so that it will also block any light reflection. (See Figure 2.)



Correct Use

DIP Switch 1 Mode Switching Emitters

DIP switch 1		Function	OFF (left)	ON (right)
	1	Picking display mode	(See note 3.)	
	2	setting		
	3	Picking indicator flash- ing speed setting (see note 1)	SLOW	FAST
3 4 5 6	4	External picking dis- play mode setting (see note 4)	Lit	Flashing
	5	NC		
	6	Frequency setting (see note 2)	Frequency A	Frequency B

Receivers

		:			
DIP switch 1		Function	OFF (left)	ON (right)	
	1	Picking display mode	(See note 3.)		
	2	setting			
1 0 N 2 0 N 3 0 4	3	Picking indicator flash- ing speed setting (see note 1)	SLOW	FAST	
	4	Output mode setting	Dark-ON	Light-ON	
6	5	Sensing distance (sen- sitivity) setting	LONG mode (1 to 3 m)	SHORT mode (0.05 to 1 m)	
	6	Not used			

- Note: 1 . The flashing speed can be changed in picking display mode (all flashing, elevator-like lighting, or accordion-like lighting) or in external picking display mode. The flashing speed varies with each display mode.
 - 2 . Mutual Interruption Attenuating Function: The frequency selector is used to switch the emitting frequency between A and B. Making the emitting frequencies of two Sensors different prevents malfunction caused by mutual interference.
 - 3 Picking Display Mode Setting of DIP Switch 1

DIP switch 1	Pin 1	Pin 2	Display mode
	OFF	OFF	All lighting (All six indicators are lit.)
	ON	OFF	All flashing (All six indicators flash simultaneously.)
1 0 2 N 3 1 4 1 5 6	OFF	ON	Elevator-like lighting (Two adjacent indicators simultaneously light so that lighting moves up and down.)
	ON	ON	Accordion-like lighting (Some or all indicators simultaneously light so that lighting moves like an accordion.)

Elevator-like Lighting Mode

O Not lit • Lit

OMRON

000000000000 LED2 O O O O O 0 C C 0 LED3 0000000 00000000000 0 0 0 LED4 000000 0 000 0 0 0 0 000 LED5 000000 0 0 0 0 0 LED6 000000000 000000000

Accordion-like Lighting Mode

Display progress LED1 O 000000000 LED2 OO 000000 .. 0 LED3 0000000000000 00 00000 . LED4 00000000 ... 00 00000 LED5 0000000000 000000 00 0 • .

4. For F3W-D052iP-L Emitters only

Wiring

Before turning ON the power, make sure that the supply voltage is within the maximum allowable voltage range.

Always connect the sync lines.

Extension cables must be 0.3 mm2 or more in cross-sectional area and 100 m or less in length (for the F3W-D052A(P) and F3W-D052B(P) only).

Be very careful not to get metal chips in the connector especially during wiring

OMRON

Incorrect wiring may damage the equipment. Make sure that the cable length and routing are appropriate to prevent the connectors and cables from getting disconnected. Always leave the operation cover closed during operation. Applying excessive force to the mode selector switch may result in damage. Do not apply a force of more than 5 N.

Cables

Make sure that the bending radius is 25 mm or more.

Installation

Install the Sensor so that its sensing face will not receive light from the sun, fluorescent lamps, incandescent lamps, and other light sources.

Do not strike the Sensor with a hammer or any other tool during the installation, otherwise the internal circuitry of the Sensor may be damaged.

Install the Emitter and Receiver in the same orientation as shown in the following figure. (The cable pullout direction must be the same.)



Use M4 screws to secure the Sensor body.

Secure the case to a tightening torque of 1.2 Nxm or less.

Reflection from Wall or Floor

If the Emitter and Receiver are installed as shown in the following illustration, all the axes may not be interrupted due to light reflection from the floor or wall. Make sure that the Emitter and Receiver detect the sensing object properly before using the F3W-D in actual operation.



M12 Connectors

Always turn OFF the power before connecting or disconnecting an M12 connector.

Always connect or disconnect an M12 connector by holding its cover.

Always tighten the fixture by hand. Using pliers may result in damage.

Insufficient tightening may loosen the connector due to vibration, resulting in failure to ensure the specified degree of protection.

Operation and Stability Status Display

The following illustration shows the indicator status corresponding to each incident level.

Install the Receiver so that the green stability indicators are both ON in light receiving status.



Note: If the Receiver is set to the stable light-receiving zone, it will become more resistant to environmental fluctuations such as temperature, voltage, dust, and setting deviation after installation. For applications where a stable light-receiving zone is not obtained, attention must be paid to environmental fluctuations

Installation Environment

Do not install the F3W-D Sensor under the following conditions.

- Where direct sunlight is received
- Where humidity is high and there is a risk of condensation Where there are corrosive gases
- Where vibration and shock are directly transmitted to the Sensor

Cleaning

- Do not use organic solvents for cleaning. Otherwise, the surfaces of the Sensor will be eroded.
- Use a soft, dry cleaning cloth.

Non Safety Area Sensor

F3ZN

Discrimination of a wide range of shapes makes this sensor ideal for a variety of applications, such as sorting, inspection, quality control and positioning



Features

Fits perfectly into installations! Protective Height

The Scanner can be produced with a beam gap of 9, 15, 30, or 60 mm, and with a sensing height of up to 1,785 mm.





Connects in series for up to 240 beams. Series Connection Specifications

Up to 3 Scanners can be connected in series to enable sensing with up to 240 beams.

* The response time varies with the length.

Support software for PCs allows functions to be set as desired with programmable I/O.

The status of the beams are output in parallel to allow height and area measurement as well as completeness checks.

- The total number of interrupted (or incident) beams can be output.
- Up to two types of status, such as the number of the highest (or lowest) beam that is interrupted (or incident), can be simultaneously output using 16 points of programmable I/O (P-I/O).

Beams can be handled in groups of a size selected by the user. Dropping position inspections and picking checks are possible.



 Beams can be divided into as many as 16 groups.
Communication (RS-485/RS-

Communication (RS-485/RS-232C) with PLC (Programmable Controllers) is supported.



RS-485/RS-232C PLC, etc.

ollers) is support

OMRON

Applications



Smarter and easier operation with PC control*, providing the optimum function for your needs.



* "Ascan" (for PCs) function setting support software required for PC integration.

Incident Level Monitoring

Conventional area sensors use ON/ OFF control. The Area Scanner facilitates analog monitoring of the incident level and so installation and operating status checks and sensitivity adjustment can be performed simply. There are also features that allow smoother threshold setting.



Scan Monitor

It is possible to keep track of ON/OFF data for all beams, together with times. This allows accurate object comparisons and checks based on a variety of settings.

*The screen images shown here may differ from the actual product.

Programmable I/O can be allocated to various measurement processes.



Main Functions of Ascan Ver. 2.10

Beam Level Graph

The light receiving sensitivity can be displayed as a graph. ON/ OFF sensitivity adjustment is possible.



Beam Level List

The light receiving sensitivity can be displayed in digital figures and incident level data can be saved in files.



Scan Monitor

The ON/OFF status can be displayed at intervals of a user-set sampling time.



P-I/O (16 Points)

The conditions set for combined ON/OFF judgement, parallel output, and group judgement can be allocated to output as required.



Combined ON/OFF Judgement

Output conditions based on the status of all the beams can be set as required (e.g., ON when 3 or more beams are incident, ON when 2 or more beams are interrupted, etc.)



Parallel Output

The output format can be selected as required. For example, it is possible to output the number of the highest incident beam and the total number of interrupted beams.



Group Judgement

Beams within an area can be handled as a group.



BANK Function Four banks can be set.

Available Models

Main Units

Sensor Infrared

Appoarance	Operating range	Boom gon	Number of beams	Soncing boight	Model	
Appearance	Operating range	Beam gap Number of beams		Sensing neight	PNP output	NPN output
	0.2 to 7 m	9 mm	21 to 125 (See *1.)	180 to 1,116 mm	F3ZN- *3 S	F3ZN- S□□□N09
а.		15 mm	13 to 120	180 to 1,785 mm	F3ZN- *3 SDDDP15	F3ZN- S□□□N15
	0.2 to 10 m 30 mm 60 mm	30 mm	7 to 60	180 to 1,770 mm	F3ZN- *3 SP30	F3ZN- S□□□N30
₽₽		4 to 30	240 to 1,740 mm	F3ZN- *3 SIIIIP60	F3ZN- S□□□N60	

*1. Models with a 9-mm beam gap can only be produced for an odd number of beams.

Received and a series of the se

Controller

Appearance	Output	Model
	PNP	F3ZP-M1P-FLK*1
	NPN	F3ZP-M1N-FLK

*1. PNP version available as at 2004

Accessories (Sold Separately)

Double-ended Connector Cable (Set of 2 for Emitter and Receiver)

Appearance	Cable length	Specification	Model	Application
	0.2 m	M12 connector (8 pins)	F39-JCR2B	Series connection or connection to the F3ZP-
The Assessment	3 m		F39-JC3B	M1□-FLK
	7 m		F39-JC7B	
	10 m		F39-JC10B	Connection to the F3ZP-M1□-FLK
6	15 m	ISTRIAI	F39-JC15B	TION

Area Scanner Function Setting Support Software (AScan)

Appearance	OS	Model
	Consult your OMRON repre- sentative.	(English version) F3ZP-CD100-E

Recommended Area Scanner Models

F3ZN-S N(P)09 and F3ZN-S N(P)09-01 (Beam gap: 9 mm)

Model	Sensing height	Number of beams
F3ZN-S0180N(P)09(-01)	180 mm	21
F3ZN-S0288N(P)09(-01)	288 mm	33
F3ZN-S0432N(P)09(-01)	432 mm	49
F3ZN-S0576N(P)09(-01)	576 mm	65
F3ZN-S0720N(P)09(-01)	720 mm	81
F3ZN-S0864N(P)09(-01)	864 mm	97
F3ZN-S1008N(P)09(-01)	1,008 mm	113
F3ZN-S1116N(P)09(-01)	1,116 mm	125

F3ZN-S N(P)15 and F3ZN-S N(P)15-01 (Beam gap: 15 mm)

Model	Sensing height	Number of beams
F3ZN-S0180N(P)15(-01)	180 mm	13
F3ZN-S0390N(P)15(-01)	390 mm	27
F3ZN-S0510N(P)15(-01)	510 mm	35
F3ZN-S0630N(P)15(-01)	630 mm	43
F3ZN-S0750N(P)15(-01)	750 mm	51
F3ZN-S0870N(P)15(-01)	870 mm	59
F3ZN-S0990N(P)15(-01)	990 mm	67
F3ZN-S1110N(P)15(-01)	1,110 mm	75
F3ZN-S1230N(P)15(-01)	1,230 mm	83
F3ZN-S1350N(P)15(-01)	1,350 mm	91
F3ZN-S1470N(P)15(-01)	1,470 mm	99
F3ZN-S1590N(P)15(-01)	1,590 mm	107
F3ZN-S1710N(P)15(-01)	1,710 mm	115
F3ZN-S1785N(P)15(-01)	1,785 mm	120

Connector Type

No extra figures at end of model number	-01 at end of model number	
ia International		STRIAL A
	(Series connection type)	

F3ZN-S N(P)30 and F3ZN-S N(P)30-01 (Beam gap: 30 mm)

Appearance	Sensing height	Number of beams
F3ZN-S0180N(P)30(-01)	180 mm	7
F3ZN-S0270N(P)30(-01)	270 mm	10
F3ZN-S0390N(P)30(-01)	390 mm	14
F3ZN-S0510N(P)30(-01)	510 mm	18
F3ZN-S0630N(P)30(-01)	630 mm	22
F3ZN-S0750N(P)30(-01)	750 mm	26
F3ZN-S0870N(P)30(-01)	870 mm	30
F3ZN-S0990N(P)30(-01)	990 mm	34
F3ZN-S1110N(P)30(-01)	1,110 mm	38
F3ZN-S1230N(P)30(-01)	1,230 mm	42
F3ZN-S1350N(P)30(-01)	1,350 mm	46
F3ZN-S1470N(P)30(-01)	1,470 mm	50
F3ZN-S1590N(P)30(-01)	1,590 mm	54
F3ZN-S1710N(P)30(-01)	1,710 mm	58
F3ZN-S1770N(P)30(-01)	1,770 mm	60

F3ZN-S N(P)60 and F3ZN-S N(P)60-01 (Beam gap: 60 mm)

Appearance	Sensing height	Number of beams
F3ZN-S0240N(P)60(-01)	240 mm	5
F3ZN-S0300N(P)60(-01)	300 mm	6
F3ZN-S0420N(P)60(-01)	420 mm	8
F3ZN-S0540N(P)60(-01)	540 mm	10
F3ZN-S0660N(P)60(-01)	660 mm	12
F3ZN-S0780N(P)60(-01)	780 mm	14
F3ZN-S0900N(P)60(-01)	900 mm	16
F3ZN-S1020N(P)60(-01)	1,020 mm	18
F3ZN-S1140N(P)60(-01)	1,140 mm	20
F3ZN-S1260N(P)60(-01)	1,260 mm	22
F3ZN-S1380N(P)60(-01)	1,380 mm	24
F3ZN-S1500N(P)60(-01)	1,500 mm	26
F3ZN-S1620N(P)60(-01)	1,620 mm	28
F3ZN-S1740N(P)60(-01)	1,740 mm	30

Ratings and Performance

Main Units

Common Ratings and Performance Data for F3ZN-S COMPC (-01 to -05) Sensors

Item	Model	F3ZN-S	F3ZN-SOOOP15	F3ZN-S	F3ZN-S			
Operating range		0.2 to 7 m		0.2 to 10 m				
Beam gap		9 mm	15 mm	30 mm	60 mm			
Number of beams		21 to 125	13 to 120	7 to 60	4 to 30			
Sensing he	ight	180 to 1,116 mm	180 to 1,785 mm	180 to 1,770 mm	240 to 1,740 mm			
Minimum d size (non-tr	etectable object ansparent)	14 mm in diameter	25 mm in diameter	40 mm in diameter	70 mm in diameter			
Light sourc	e (wavelength)	Infrared LED (870 nm)						
Supply volt	age	24 VDC ±10%; ripple (p-p): 10% max.						
Current cor no-load cor	nsumption (under nditions)	Emitter: 170 mA max.; Receiver: 120 mA max.						
Control out	put	PNP:PNP transistor output (load current: 50 mA) Output 1: Light ON Output 2: Dark ON (default)						
External dia	agnosis input	Open or 0 to 1.5 VDC: ina 9 to 24 VDC: active (emitt	ctive (emitting) ing OFF), short-circuit curi	rent is 3 mA max.				
	Emitter	Incident level indicators (g light. Error indicators (red): 3 LE Power indicator (green): T External diagnosis indicator	ncident level indicators (green): 5 LED indicators that turn ON/OFF according to the amount of incident ght. irror indicators (red): 3 LED indicators that turn ON/OFF according to the type of errors that occur. Power indicator (green): Turns ON for normal operation; flashes when errors occur. External diagnosis indicator (orange): Turns ON in response to external diagnosis input.					
Indicators	ors Incident level indicators (green): 5 LED indicators that turn ON/OFF according to the amoulight. Receiver Error indicators (red): 3 LED indicators that turn ON/OFF according to the type of errors that Control output 1 operation indicator (orange): Turns ON when light is incident. Control output 2 operation indicator (orange): Turns ON when light is interrupted (factory s Power indicator (green): Turns ON for normal operation; flashes when errors occur. Function indicator (green): Turns ON when option is set.							
Protection		Reverse polarity protection	n (for power supply) and o	utput short-circuit protectio	n			
Response	time	Refer to page D-368 for de	etails.					
Ambient lig	ht intensity	Light intensity on the receiver surface: Incandescent lamp: 3,000 lx max. Sunlight: 10,000 lx max.						
Ambient te	mperature	Operating: -10 to 55 °C; Storage: -30 to 70 °C (with no icing or condensation)						
Ambient hu	ımidity	Operating/storage: 30% to 95% (with no condensation)						
Insulation r	esistance	20 MΩ min. (at 500 VDC)						
Dielectric s	trength	1,000 VAC, 50/60 Hz for 1 min						
Vibration re (malfunctio	esistance n)	10 to 55 Hz with a 0.7-mm double amplitude, 20 sweeps each in X, Y, and Z directions						
Shock resist (malfunctio	stance n)	100m/s², 1,000 times each in X, Y, and Z directions						
Degree of p	protection	IP65 (IEC)						
Connection	method	M12 connector						
Weight (in	packaging)	(Protective height + 100) >	< 2 + 2,100 g					
	Case	Aluminum						
Materials	Front cover	Acrylic (PMMA resin)						
	Cable	Oil-resistant PVC						
Accessories		Top, bottom, and intermediate* mounting brackets, and instruction manual						

* Intermediate mounting brackets are supplied only with the following models:

Models with a total length between 640 and 1,280 mm: One set (i.e., one each for emitter and receiver)

Models with a total length greater than 1,280 mm: Two sets (i.e., two each for emitter and receiver) * PNP models available as of 2004.

OMRON

Main Units Common Ratings and Performance Data for F3ZN-S COMPARIANCE (-01 to -05) Sensors

Item	Model	F3ZN-S	F3ZN-S	F3ZN-S	F3ZN-S			
Operating I	ange	0.2 to 7 m		0.2 to 10 m				
Beam gap		9 mm	15 mm	30 mm	60 mm			
Number of beams		21 to 125	13 to 120	7 to 60	4 to 30			
Sensing he	eight	180 to 1,116 mm	180 to 1,785 mm	180 to 1,770 mm	240 to 1,740 mm			
Minimum d size (non-ti	etectable object ansparent)	14 mm in diameter	25 mm in diameter	40 mm in diameter	70 mm in diameter			
Light sourc	e (wavelength)	Infrared LED (870 nm)						
Supply volt	age	24 VDC ±10%; ripple (p-p): 10% max.						
Current cor no-load cor	nsumption (under nditions)	Emitter: 170 mA max.; Receiver: 120 mA max.						
Control out	put	NPN:NPN transistor outpu Output 1: Light ON Output 2: Dark ON (defa	ut (load current: 50 mA) ault)					
External dia	agnosis input	Open or 9 to 24 VDC: inat 0 to 1.5 VDC: active (emit	ctive (emitting) ting OFF), short-circuit cu	rrent is 3 mA max.				
	Emitter	Incident level indicators (c light. Error indicators (red): 3 Lt Power indicator (green): 7 External diagnosis indicat	ncident level indicators (green): 5 LED indicators that turn ON/OFF according to the amount of incident ght. Fror indicators (red): 3 LED indicators that turn ON/OFF according to the type of errors that occur. Yower indicator (green): Turns ON for normal operation; flashes when errors occur. External diagnosis indicator (orange): Turns ON in response to external diagnosis input.					
Indicators	Receiver	ncident level indicators (green): 5 LED indicators that turn ON/OFF according to the amount of incident ight. Error indicators (red): 3 LED indicators that turn ON/OFF according to the type of errors that occur. Control output 1 operation indicator (orange): Turns ON when light is incident. Control output 2 operation indicator (orange): Turns ON when light is interrupted (factory setting). Power indicator (green): Turns ON for normal operation; flashes when errors occur. Function indicator (green): Turns ON when option is set.						
Protection		Reverse polarity protectio	n (for power supply) and o	utput short-circuit protectio	n			
Response	time	Refer to page D-368 for details.						
Ambient lig	ht intensity	Light intensity on the receiver surface: Incandescent lamp: 3,000 lx max. Sunlight: 10,000 lx max.						
Ambient te	mperature	Operating: -10 to 55 °C; Storage: -30 to 70 °C (with no icing or condensation)						
Ambient hu	ımidity	Operating/storage: 30% to 95% (with no condensation)						
Insulation r	esistance	20 MΩ min. (at 500 VDC)						
Dielectric s	trength	1,000 VAC, 50/60 Hz for 1 min						
Vibration re (malfunctio	esistance n)	10 to 55 Hz with a 0.7-mm double amplitude, 20 sweeps each in X, Y, and Z directions						
Shock resist (malfunctio	stance n)	100m/s ² , 1,000 times each in X, Y, and Z directions						
Degree of p	protection	IP65 (IEC)						
Connection	method	M12 connector						
Weight (in	packaging)	(Protective height + 100)	× 2 + 2,100 g					
	Case	Aluminum	Aluminum					
Materials	Front cover	Acrylic (PMMA resin)	sin)					
	Cable	Oil-resistant PVC						
Accessories		Top, bottom, and intermediate* mounting brackets, and instruction manual						

*

Intermediate mounting brackets are supplied only with the following models: Models with a total length between 640 and 1,280 mm: One set (i.e., one each for emitter and receiver)

Models with a total length greater than 1,280 mm: Two sets (i.e., two each for emitter and receiver)

Main Units Controller

Item	Model	F3ZP-M1N-FLK	F3ZP-M1P-FLK		
Supply voltage		24 VDC ±10%; ripple (p-p): 10% max.			
Current consumption		50 mA max. (not including the Sensor's current consumption and output current)			
Connectabl	e Sensors	F3ZN-S	F3ZN-SDDDPDD		
Number of connectable Sensors		3 sets of Sensors and Sensor configurations with 240 beams.			
Output (OUT1, OUT2, OUTPUT (OUT3, ERROR, BANK OUT, TCH OUT))		Load supply voltage: 24 VDC max.; NPN open col- lector output (load current: 30 mA max.)	Load supply voltage: 24 VDC max.; PNP open collector output (load current: 30 mA max.)		
Input (TCH, EDI, RESET, BANKIN, BANK1, BANK2)		DC input: Maximum input voltage: 24 V ±10% Operating voltage: ON voltage: 9 V min.; OFF voltage: 1.5 V max. Input current: 3 mA max.			
	Output	Function can be configured by AScan software.			
-		Load supply voltage: 24 VDC max.			
Program mable I/O		NPN open collector output (load current: 50 mA max.)	PNP open collector output (load current: 30 mA max.)		
to D15)	Input	DC input; Input voltage: 24 V ±10%; Input current: 3 mA max.			
	Operating voltage	ON voltage: 9 V min. OFF voltage: 1.5 V max.	ON voltage: 1.5 V max. OFF voltage: 9 V min.		
	Communications ports	RS-232 port (D-sub 9-pin connector) and RS-485 port (terminal block) (DIP-Switch setting)			
Communi-	Communications protocol	CompoWay/F			
functions	Unit numbers	00 to 15 (Set by rotary switch.)			
	Baud rate	9,600, 14,400, 19,200, 38,400, 57,600, or 115,200 bps (Selected by switch.)			
	Data configuration	Data bits: 7; Parity: Even; Start bits: 1; Stop bits: 2; No flow control			
Clock function		Year, month, day, hour, minute, second, and day of week			
Indicators		POWER (green), MODE (green), RUN (green), and ERROR (red)			
Protection		Reverse polarity protection (for power supply) and output short-circuit protection			
Response time		Refer to page D-368 for details.			
Ambient temperature		Operating: -10 to 55 °C; Storage: -20 to 75 °C (with no icing or condensation)			
Ambient humidity		Operating/storage: 10% to 90% (with no condensation)			
Insulation resistance		20 M Ω min. (at 500 VDC) between all terminals and the case			
Dielectric strength		1,000 VAC, 50/60 Hz for 1 min; Leakage current: 10 mA max.			
Vibration resistance (destruction)		Conforms to IEC 60068-6 10 to 57 Hz with 0.075-mm double amplitude and 57 to 150 Hz with acceleration of 9.8 m/s ² for 80 min each in X, Y, and Z directions (10 sweeps \times 8 min per sweep = 80 min)			
Shock resistance (destruction)		Conforms to IEC 60068-27 147 m/s ² , 3 times each in X, Y, and Z directions			
Structure		Built into panel, DIN-Rail mounting			
Accessories		RS-232C connector (plug, cover) and instruction manual			

* PNP models available as of 2004

Response Times

Detection Output Response Times

The response times vary with the length (sensing height) of the Sensor.

Мо	del	Sensing height (mm)			
F3ZN-S	(P)09 (-01 to -05)	0180 to 0441	0450 to 0756	0765 to 1071	1080 to 1116
F3ZN-S R(P)15/30/60		0180 to 0735	0750 to 1260	1275 to 1785	
Control output 1	$ON \rightarrow OFF$	11 ms	13.5 ms	16 ms	16.5 ms
Control output	$OFF \rightarrow ON$	44 ms	54 ms	64 ms	66 ms
Control outputs 2 and	$ON \rightarrow OFF$	22 ms	27 ms	32 ms	33 ms
3	$OFF \rightarrow ON$	55 ms	67.5 ms	80 ms	82.5 ms
Programmable I/O (D00 to D15)		33 ms	40.5 ms	48 ms	49.5 ms

Note: The response times for control outputs 2 and 3 given in the above table are for when the output is set to "Light-ON" (i.e., ON if the beam is incident), which is the same setting as control output 1.

Timing Chart for the Period between Workpiece Detection and Output Response



TR: Response time of control output 1 (ON→OFF). (Refer to Detection Output Response Times.)

Minimum detection time: The minimum time in which changes in the interrupted (or incident) state can be detected.

Minimum detection time for programmable I/O	TR×2
Minimum detection time for control outputs 1, 2, and 3 (interrupted) =	TR
Minimum detection time for control outputs 1, 2, and 3 (incident) =	$TR \times 3$

Maximum delay time (maximum response time): The maximum time between light interruption (or incidence) and the resulting change in output.

Maximum delay time for programmable I/O output (D00 to D15)	=	$TR \times 3$
Maximum delay time for control output 1 (interrupted)	=	TR
Maximum delay time for control output 1 (incident)	=	$TR \times 4$
Maximum delay time for control outputs 2 and 3 (interrupted)	=	$TR \times 2$
Maximum delay time for control outputs 2 and 3 (incident)	=	$TR \times 5$

Note: Consult your OMRON representative for details on response times when the Sensors are connected in series.

I/O Block Circuit Diagram







- *1. INPUT is used for RESET and TCH.
- *2. OUTPUT is used for OUT3, ERROR, and TCH OUT.
- *3. EDI is external diagnosis input.
- *4. COM OUT is connected to +24V.
 *5. COM IN is connected to 0V.







*6. INPUT is used for RESET and TCH.

*7. OUTPUT is used for OUT3, ERROR, and TCH OUT.

- *8. EDI is external diagnosis input.
 *9. COM OUT is connected to +24V.
- *10. COM IN is connected to 0V.

Controller Communications Settings

Mode Selection Switch

If necessary, make changes to the communications settings using the mode selection switch. The baud rate is factory-set to 9,600 bps and the unit number is factory-set to 1.



Be sure to set pin 9 of the DIP switch to OFF.

This is the termination setting for RS-485 communications. Set to ON if used as the termination point (normally OFF).

Engineering Data (Typical Examples)

Parallel Operating Range

F3ZN-S N(P)09(-01)

Angular Range (Angle of Elevation) F3ZN-SOO(P)09(-01)



Angular Range (Angle of Rotation) F3ZN-S R (P)09(-01)



<u> M</u> WARNING

Do not use the F3ZN area scanner as a safety device in pressing machines or as a safety device for protecting the human body in any other kind of installation. Use F3S safety sensors.

- (1) Do not use the Scanner in environments where flammable or explosive gases are present.
- (2) <u>The Scanner cannot be used as a safety device for protecting</u> <u>the operator's hands or any other part of the body</u> in pressing machines, shears, rolling machines, spinning machines, cotton mill machines, or robots.
- (3) This product is designed for applications such as detecting the entrance of human bodies into the operator area and detecting moving objects. It is not designed for use as a safety device.
- (4) If this product is used in exported equipment in any of the ways 1) to 4) listed below, OMRON shall accept no responsibility for any problems concerning local law or product liability.
 - 1) Application as a safety device for preventing injury resulting from the operator's hands or any other part of the body entering a dangerous area
 - 2) Application in interlocks in machinery or installations
 - 3) Application as a safety device that detects the presence of the operator's hands or any other part of the body in a dangerous area and stops the machinery or installation in which it is incorporated
 - 4) Application as a sensing device in installations for preventing access to dangerous areas by detecting the operator's hands or any other part of the body, and opening/closing a window or door

When using more than one Scanner installed close together, in order to prevent malfunctions due to mutual interference, be sure to observe the points mentioned under *Preventing Mutual Interference*.

Application Precautions

In order to ensure safety, be sure to observe the points described below.

• Wiring Operating Environment

- Do not attempt to disassemble, repair, or modify the product.
- Be sure to turn OFF power to the system before installing or replacing the product.

Correct Use

Designing the System

Operation at Power-ON

After turning ON the power, one second must elapse before the Sensor can perform sensing. Therefore, do not use other related devices until at least one second has elapsed after turning the power ON. If the load and the Sensor are connected to different power supplies, be sure to turn ON the power to the Sensor first.

Preventing Mutual Interference

• When using more than one Sensor installed close together, separate them by the distances ℓ_1 or ℓ_2 (at least 1.5 times the distances shown under page D-371 *Parallel Operating Range*) in the way shown below.



• Install barriers to block out light from other emitters. (See Fig. 1.)

In addition to direct light, light may also be reflected off walls, the floor, and other surfaces. Install the barriers so that all light from other emitters, including reflected light, is blocked. (See Fig. 2.)



OMRON

• Wiring

Connection

- To extend the connection distance, use lines with a crosssectional area of at least 0.3 mm², and do not extend to a distance exceeding 100 m. Use a shielded cable, and connect the shield line to the 0-V line.
- Incorrect wiring may result in damage to devices. Ensure that connectors and cables do not come loose by giving careful consideration to the cable length and installation arrangement.

Cables

In configurations where the cable must be bent, allow at least the dimensions shown below. (Cable's minimum bending radius: 36 mm.)



Installation

Installation Precautions

- Install the Sensor so that no beams of strong light, such as sunlight, fluorescent light, or incandescent light can enter at an angle less than the effective aperture angle of the Sensor.
- Do not strike the Sensor with a hammer during installation. Doing so may damage the internal structure.
- Install the Sensor so that the cables on the emitter and receiver point in the same direction. (See below.)



- Secure the Controller using M4 screws.
- Secure the case using a tightening torque of 1.2 N·m max. Reflection off Walls and Floors

If the Sensor is installed in the way shown below, the beam may not be blocked properly due to the reflection of light off the floor. The same problem can also occur with light reflected off walls. Check that the sensing object can be detected properly before starting actual operation.



Adjustment

- **Operation/Stability Indicators**
- The indicators operate according to the incident level in the way shown below.
- Set the Scanner so that all the incident level indicators are lit.



Note: The Sensor's ON/OFF indication and the Controller's ON/OFF status may vary, depending on the settings made by the user.

Dimensions

Main Units

Sensor

F3ZN-SOON(P) F3ZN-S



Note: In the above diagram, the intermediate mounting bracket (refer to page D-376) is shown mounted on the left as an example. If the intermediate mounting bracket is mounted on the right, the mounting holes must also be on the right.



The dimensions for different model numbers can be calculated using the following formulae. F3ZN-S Rev N(P)09
 Dimension C (protective height) = The 4 digits in the model number Dimension A = C + 95Dimension B = C + 63Dimension D = 15.5 Dimension E1 = C + 31Dimension E2 = C + 9Dimension F = See table below. Dimension P = 9Number of Dimension Protective intermedi-F (See height (C) ate mountnote.) ing brackets Up to 611 0 ---612 to F = B/21 1,116 Note: When not using the value of F obtained with the above calculation, use a value not exceeding 670 mm. F3ZN-SDDDN(P)15,

F3ZN-S N(P)30, or F3ZN-S N(P)60 Dimension C (protective height) = The 4 digits in the model number Dimension A = C + 101Dimension B = C + 69Dimension D = 18.5 Dimension E1 = C + 37 Dimension E2 = C + 15Dimension F = See table below. Dimension P = 15Number of

Protective height (C)	intermedi- ate mount- ing brackets	Dimension F (See note.)
Up to 611	0	
612 to 1,230	1	F = B/2
1,231 to 1,785	2	F = B/3

Note: When not using the value of F obtained with the above calculation, use a value not exceeding 670 mm

Consult your OMRON representative for other dimension diagrams.

Mounting Hole Dimensions

OMRON

OMRON

CÔNG TY CỔ PHẦN CÔNG NGHỆ HỢP LONG

Controller F3ZP-M1N-FLK F3ZP-M1P-FLK



INDUSTRIAL AUTOMATION

Accessories





Emitter: Gray Receiver: Black